

# Building Automation & HVAC Modernization Brief

Optimize critical facilities with high-efficiency WEG drives, PLCs, and control power.

Deploy CFW501 and CFW701 drives with BACnet, redundancy, and fire override sequences.

Use PLC500 and TPW HMIs to unify BAS integration, analytics, and alarm escalation.

Design control panels with WPS power supplies, CSW pilots, and SRW safety for code.

Checklist covers sequence validation, trend logging, and lifecycle service planning.

Contact Gross Automation: [sales@grossautomation.com](mailto:sales@grossautomation.com) | +1-262-252-1600