

Water & Wastewater Modernization Brief

Align WEG drives, PLCs, and controls around resilient SCADA-ready pump stations.

Deploy CFW501 and CFW701 drives with bypass cabinets for filtration and lift stations.

Leverage PLC500 redundancy and remote I/O for secure level control and alarming.

Integrate SRW safety, MPW breakers, and BTB terminal blocks for service-friendly panels.

Includes startup checklists, SCADA tag maps, and lifecycle service milestones.

Contact Gross Automation: sales@grossautomation.com | +1-262-252-1600