



Pump Genius Multiplex V2.10 Application Information

Equipment: CFW-11

Firmware Version: Ve5.31

WLP Software Version: V9.82 or higher

New Application Version: PGMPX_CFW11_en_V2_10.apl

Old Application Version: PGMPX_CFW11_en_V2_02.apl

Document Number (Application Manual): 10001912293 / 01

Functional deviations in the old application version

- 1) It was corrected texts in monitoring dialogs.

Changes in the new application version

- 1) It was changed the function of P1011, P1012, P1013, P1014 and P1015.



NOTE!

Appendix 1 shows how to import Pump Genius Multiplex application to WLP.

Appendix 1 – How to Import Application to WLP

- 1) In the WLP Ladder Programmer, in “Tools” menu, select the “Import Application to WLP” option;
- 2) Search “PGMPX_CFW11_en_V2_10.apl” archive and press “OK”;
- 3) The Pump Genius Multiplex application will be imported to WLP;
- 4) To select the application, in “Tools” menu, “Application” option, “CFW11”, “Create”, “Pump Genius”, select “Multiplex Control” option.